



TRIAD 2 RANGE

Programmable digital transducers
with 1 to 4 analog outputs.
Programmable accuracy class.



- Up to 4 programmable analog outputs
- 4 kV insulation
- Configurable and modifiable:
using the TRIADJUST 2 software
- Adjustable accuracy within Class 0.1 as per
IEC 60688
- Digital output available as an option

MAIN SPECIFICATIONS

Quantities measured: 1, 2, 3, 4 to be chosen from I, V, U, F, PF, P, Q, S, cosφ, φ, ϕU, ϕV, tanφ

Configuration of TRIAD 2: in factory or by the user with
the TRIADJUST 2 software

Accuracy (programmable): class 0.1/0.15/0.2/0.5/1

Current inputs: 1 A and 5 A

Voltage inputs: 100 to 480 V (ph-ph)
or 100/ $\sqrt{3}$ to 480 / $\sqrt{3}$ V (ph-N)

Transfer curves: linear, 2 slopes or quadratic

Output signals: $\pm 1\text{mA}$, $\pm 5\text{mA}$, $\pm 20\text{mA}$, $\pm 1\text{V}$, $\pm 10\text{V}$

Response time down to 50 ms

Operating frequency: 50 or 60 Hz

Auxiliary power supply with wide dynamic range:
80 to 265 V ac/dc or 19 to 58 Vdc

Compliance with CE directive

Digital technology



Multi-function,
economical
instrument with
4 functions in
the same casing



Communication:
Ethernet, RS 485
or optical head



Accessibility
and safety:
large-dimension
terminals
Insulated circuits



ZOOM

Ergonomic:
easy mounting
on DIN rail or
switchboard

User sectors



tertiary



industry



energy generation



energy transmission & distribution



nuclear



energy efficiency



rail

METERS AND POWER MONITORS

FACTORY-PROGRAMMABLE

- The transducer delivered is ready to operate and can be connected to the electrical network in order to deliver output signals tailored for your installation.
- To benefit from this, you simply need to know the exact specifications of your electrical installation:
 - Type of network: single-phase, split-phase, balanced or unbalanced three-phase, 3 or 4 wires.
 - Type of electrical connections.
 - Number of electrical quantities to be measured: 1, 2, 3 or 4.
 - Precise measurement ranges of the input/output quantities to be measured.

Users can modify a factory configuration at any time with the TRIADJUST 2 software if the specifications of the electrical network change.

ENVIRONMENT AND STANDARDS

EMC immunity (standard of reference: IEC 60688, IEC 61326-1, IEC 61000-6-5)	
Shock voltage as per IEC 61000-4-5	2 kV in differential mode 4 kV in common mode
Oscillating wave as per IEC 61000-4-12	1 kV in differential mode 2.5 kV in common mode
Fast electrical transients in bursts as per IEC 61000-4-4	2 kV on power supply 2 kV on inputs/outputs
Electrostatic discharge as per IEC 61000-4-2	8 kV in the air 6 kV in contact
EM radiated field as per IEC 61000-4-3	10 V/m (80 Mhz to 3 GHz)
Voltage dips as per IEC 61000-4-11	30% reduction during 20 ms 60% reduction during 1 s
Voltage interruptions as per IEC 61000-4-11	100% reduction during 100 ms 100% reduction during 100 ms

EMC emissions	
Radiated and conducted	As per CISPR11
Climatic specifications (IEC 60068 2-1/2-2/2-30)	
Operating temperature	-10°C to +55°C
Storage temperature	-40°C to +70°C
Relative humidity	≤ 95% to 55°C
Safety specifications (IEC 61010-1)	
Installation category	3
Pollution level	2
Fire resistance	UL94, severity V0
Mechanical specifications (IEC 60068 2-6/2-27/2-29/2-32/2-63)	
Protection rating	IP 20
Mechanical shocks	IEC 60068-2-27
Vibrations	IEC 60068-2-6
Drop test with packaging	NF H0042-1

MOUNTING ACCESSORIES

Model	Reference
Plate mounting for T1xy	ACCT 1007
Plate mounting for T3xy	ACCT 1006

PROGRAMMABLE VIA TRIADJUST 2


- With the TRIADJUST 2 software and one of the 3 communication modes available (Ethernet, RS485 or optical head) you can program all the parameters characterizing a TRIAD 2 transducer.
- To do so, simply choose a model which suits your electrical installation:
 - Type of network: split-phase, balanced or unbalanced three-phase, 3 or 4 wires.
 - Number of analog outputs required (1, 2 3 or 4).
 - Value of the auxiliary source.
- You are then free to configure the TRIAD 2 transducer delivered as you wish and to print out the stickers corresponding to the parameters programmed.

CASING

Weight	320 g (T1xy) / 700 g (T3xy)
Mounting	DIN rail 43700 or plate mounting
Connection	Terminals with mobile stirrup clamp with screw for 4 single-wire 6 mm ² conductors or 2 multi-wire 4 mm ² conductors

HARDWARE IDENTIFICATION

The TRIAD 2 T1xy and T3xy are fully configurable with the TRIADJUST 2 software which allows users to modify the characteristics of their products right up to the last minute.



Example:

T314 = Large-model TRIAD 2 with optical head and RS485
+ 4 analog outputs

NETWORK ANALYZERS

CURRENT TRANSFORMERS AND SHUNTS

TRANSDUCERS

PANEL METERS AND SYNCHROCOUPLER

AUXILIARY RELAYS

SERVICES AND TRAINING

Network	Function	T1xy model	T3xy model
Single-phase	V	■	■
	I	■	■
	F	■	■
	P	■	■
	Q	■	■
	S	■	■
	PF	■	■
	Tanφ	■	■
	Cosφ	■	■
	φ	■	■
	Energies*	■	■
	U12, U23, U31	■	■
	I1, I2, I3	■	■
	F	■	■
	Pt	■	■
	Qt	■	■
Balanced 3-phase, 3 wires	St	■	■
	PFt	■	■
	Tanφ	■	■
	Cosφt	■	■
	φt	■	■
	Energies*	■	■
	V1, V2, V3	■	■
	U12, U23, U31	■	■
	I1, I2, I3	■	■
	F	■	■
	P1, P2, P3, Pt	■	■
	Q1, Q2, Q3, Qt	■	■
	S1, S2, S3, St	■	■
	PF1, PF2, PF3, PFt	■	■
	Tanφ	■	■
Balanced 3-phase, 4 wires	Cos (φ1, φ2, φ3, φt)	■	■
	φ1, φ2, φ3, φt	■	■
	Energies*	■	■
	V1, V2, V3	■	■
	U12, U23, U31	■	■
	I1, I2, I3	■	■
	F	■	■
	P1, P2, P3, Pt	■	■
	Q1, Q2, Q3, Qt	■	■
	S1, S2, S3, St	■	■
	PF1, PF2, PF3, PFt	■	■
	Tanφ	■	■
	Cos (φ1, φ2, φ3, φt)	■	■
	φ1, φ2, φ3, φt	■	■
	φ (U12/U23, U23/U31, U31/U12)	■	■
Unbalanced 3-phase, 3/4 wires	φ (V1/V2, V2/V3, V3/V1)	■	■
	Current unbalance	■	■
	Energies*	■	■
	V1, V2	■	■
	U12	■	■
	I1, I2	■	■
	F	■	■
	P1, P2, Pt	■	■
	Q1, Q2, Qt	■	■
	S1, S2, St	■	■
	PF1, PF2, PFt	■	■
	Tanφ	■	■
	Cos (φ1, φ2, φt)	■	■
	φ1, φ2, φt	■	■
	φ (V1/V2)	■	■
Split-phase	I1 signed, I2 signed	■	■
	Energies*	■	■

* Accessible via the product's Modbus communication

TRIAD 2 Programmable model

ELECTRICAL SPECIFICATIONS

Voltage input	
Rated value	T1: from 57.7 Vac to 276 Vac max. T3: from 57.7 Vac to 480 Vac max.
Frequency	50 Hz: 42.5...57.5 Hz 60 Hz: 51...69 Hz
Max. measured voltage on primary	1 MV (ph-ph)
Acceptable overloads	T1: 300 Vac permanent - 460 Vac / 10s T3: 520 Vac permanent - 800 Vac / 10s
Consumption	< 0.2 VA
Input impedance	400 kΩ
Current inputs	
Rated value	0 to 10 A max.
Max. measured current on primary	40,000 A
Acceptable overload	50 In / 1 s
Consumption	< 0.15 VA
Auxiliary power supply	
High level	80 / 265 Vac (50/60 Hz) – 110 to 375 Vdc
Low level	19 / 58 Vdc
Consumption	High level T1: 3.3 VA to 8.5 VA max. T3: 9 VA to 20 VA max. Low level T1: 3.2 W to 5.5 W max. T3: 5.5 W to 11 W max.
Analog outputs	
Rated values	Current ± 1mA, ± 5mA, ± 20mA Tension ± 1 V, ± 10 V
Acceptable resistive load	15 V / Io ⁽¹⁾ ≥ 1 kΩ
Acceptable capacitive load	0.1 µF
Overrun	1.2 Io ⁽¹⁾ 1.2 Uo ⁽¹⁾
Peak-peak residual wave	± 0.2 % of Io ⁽¹⁾ ± 0.2 % of Uo ⁽¹⁾
Programmable response time	50 ms – 100 ms – 200 ms – 500 ms – 1 s
Transfer curve	Linear, 2 slopes or quadratic

(1) Io = output current, Uo = output voltage

COMMUNICATION

	Optical head	Ethernet	RS485
Connection	USB (PC) Optical (product)	RJ45	2 wires Half-duplex
Protocol	MODBUS RTU mode	MODBUS / TCP RTU mode	MODBUS / JBUS RTU mode
Speed	38,400 bauds	10 base T	2,400 to 115,200 bauds
Parity	-	-	Even, odd or none
JBus addresses	-	-	1 to 247
Transmission length	2 m	100 m	As per EIA 485

METROLOGICAL SPECIFICATIONS

Measurements	Accuracy class over measurement range (as per IEC 60688)				
	RT = 50 ms*	RT = 100 ms*	RT = 200 ms*	RT = 500 ms*	RT = 1s*
V, U, I, F, P, Q, S, PF, Tanφ, Cosφ, φ, φU, φV**	± 1 %	± 0.5 %	± 0.2 %	± 0.15 %	± 0.1 %


* RT: Response time for F = 50 Hz

* These values may change according to the input and output measurement ranges










** Phase angle between voltages for φU and φV

ELECTRICAL CONNECTIONS - SINGLE-PHASE NETWORK

I1, F:




V1, F:


V1, I1, P1, Q1, S1, PF1, F,
TAN ϕ , Cos ϕ 1, ϕ 1:

BALANCED 3-PHASE, 3-WIRE NETWORK







U12, U23, U31, F:



I1, I2, I3, F:




U12, U23, U31, I1, I2, I3, Pt, St, Qt, PFt, F, TAN ϕ , Cos ϕ , ϕ t:




⚠ Phase rotation authorized

BALANCED 3-PHASE, 4-WIRE NETWORK




V1, V2, V3, U12, U23, U31 F:





I1, I2, I3, F:





V1, V2, V3, U12, U23, U31, I1, I2, I3, P1, P2, P3, Pt, S1, S2, S3, St, Q1, Q2, Q3, Qt, PF1, PF2, PF3, PFT, F, TAN ϕ , Cos ϕ 1, Cos ϕ 2, Cos ϕ 3, Cos ϕ t, ϕ 1, ϕ 2, ϕ 3, ϕ t:




TD224



TD225




TD226




Phase rotation authorized

UNBALANCED 3-PHASE, 3-WIRE NETWORK





**U12, U23, U31, F,
Angle (U12/U23, U23/U31, U31/U12):**



**V1, V2, V3, U12, U23, U31, F,
Angle (V1/V2, V2/V3, V3/V1),
Angle (U12/U23, U23/U31, U31/U12):**












I1, I2, I3, F:



UNBALANCED 3-PHASE, 3-WIRE NETWORK (CONTINUED)


**U12, U23, U31, I1, I2, I3, Pt, St, Qt, PFt, F, TAN φ , Cos φ t, φ t,
Angle (U12/U23, U23/U31, U31/U12):**

**V1, V2, V3, U12, U23, U31, I1, I2, I3, P1,
P2, P3, Pt, S1, S2, S3, St, Q1, Q2, Q3,
Qt, PF1, PF2, PF3, PFt, F, TAN φ , Cos φ 1,
Cos φ 2, Cos φ 3, Cos φ t, φ 1, φ 2, φ 3, φ t,
Angle (V1/V2, V2/V3, V3/V1),
Angle (U12/U23, U23/U31, U31/U12):**




UNBALANCED 3-PHASE, 4-WIRE NETWORK




I₁, I₂, I₃, F:



V₁, V₂, V₃, U₁₂, U₂₃, U₃₁, F,
Angle (V₁/V₂, V₂/V₃, V₃/V₁),
Angle (U₁₂/U₂₃, U₂₃/U₃₁, U₃₁/U₁₂):




V₁, V₂, V₃, U₁₂, U₂₃, U₃₁, I₁, I₂, I₃, P₁,
P₂, P₃, Pt, S₁, S₂, S₃, St, Q₁, Q₂, Q₃,
Qt, PF₁, PF₂, PF₃, PF_t, F, TAN ϕ , Cos ϕ ₁,
Cos ϕ ₂, Cos ϕ ₃, Cos ϕ _t, φ_1 , φ_2 , φ_3 , φ_t
Angle (V₁/V₂, V₂/V₃, V₃/V₁),
Angle (U₁₂/U₂₃, U₂₃/U₃₁, U₃₁/U₁₂):




SPLIT-PHASE




I₁, I₂, F:




V₁, V₂, U₁₂, F, Angle (V₁/V₂) rad,
Angle (V₁/V₂) deg:



V₁, V₂, U₁₂, I₁, I₂, P₁, P₂, Pt, Q₁, Q₂, Qt, S₁, S₂, St, PF₁, PF₂, PF_t, F, tan ϕ , Angle (V₁/V₂) rad, Angle (V₁/V₂) deg, cos φ_1 , cos φ_2 , cos φ_t , φ_1 Fund. rad, φ_2 Fund. rad, φ_t Fund. rad, φ_1 Fund. deg, φ_2 Fund. deg, φ_t Fund.. deg, Angle V₁/V₂ Fund. deg, I₁ (signed), I₂ (signed):





DIMENSIONS (IN MM)



All models


Panel drilling diagram for plate mounting



Weight: 320 g

Weight: 700 g

Accessory for plate mounting with screw (option)



TRIAD 2 PROGRAMMABLE VIA TRIADJUST 2

T O O R D E R													
			T1 – SMALL MODEL (60 x 81 x 120.5 mm)		T3 – LARGE MODEL (120 x 81 x 120.5 mm)								
			Without tropicalization	With tropicalization	Without tropicalization				With tropicalization				
			Number of outputs	Number of outputs	Number of outputs				Number of outputs				
Link	Output	Alimentation	1	1	1	2	3	4	1	2	3	4	
Optical	± 20 mA	80 - 265 V AC/DC	P01380001	P01380002	P01380101	P01380103	P01380105	P01380107	P01380102	P01380104	P01380106	P01380108	
		19 - 58 V DC	P01380003	P01380004	P01380109	P01380111	P01380113	P01380115	P01380110	P01380112	P01380114	P01380116	
	± 10 V	80 - 265 V AC/DC	P01380005	P01380006	P01380117	P01380119	P01380121	P01380123	P01380118	P01380120	P01380122	P01380124	
		19 - 58 V DC	P01380007	P01380008	P01380125	P01380127	P01380129	P01380131	P01380126	P01380128	P01380130	P01380132	

TRIAD 2 FACTORY-PROGRAMMABLE

1 Model - Frequency

T1	Small model – 1 analog output
T3	Large model – 1 to 4 analog output(s)
0	50 Hz
1	60 Hz

2 Network

0	Single-phase
1	Balanced 3-phase, 3 wires
2	Balanced 3-phase, 4 wires
3	Unbalanced 3-phase, 3 wires
4	Unbalanced 3-phase, 4 wires
5	Split-phase

3 Communication - Connection

0	Without
1	RS485
2	Ethernet

Indicate the diagram number. E.g. TD204

4 Supply

0	80-265 Vac / 110-375 Vdc
1	19-58 V DC

5 Tropicalization

0	Without
1	With

6 Inputs

Voltage	Indicate direct voltage to be measured or the VT ratio
Current	Indicate direct current to be measured or the CT ratio

7 Number of analog outputs

0	Without (Choice of a minimum communication)
1	1 output
2	2 outputs (T3 model only)
3	3 outputs (T3 model only)
4	4 outputs (T3 model only)

8 Analog outputs

Indicate for each output:

a-	Quantity to be measured
b-	Transfer curve
c-	Input signal: Min – Breaking point - Max
d-	Measurement unit
e-	Output signal: Min – Breaking point - Max

9 Analog output ratings*

0	- 20 mA to + 20 mA
1	- 5 mA to + 5 mA
2	- 1 mA to + 1 mV
3	- 10 V to + 10 V
4	- 1 V to + 1 V

* Attention: option 0 is not suitable for use with the -5 mA to +5 mA and -1 mA to +1 mA ratings.
Option 3 is not suitable for use with the -1 V to +1 V rating.

To simplify the procedure when ordering you can send us the form on page 165.

FACTORY-PROGRAMMED TRIAD 2: ORDER FORM

1 - Model / Hz	2 - Network		3 - Communication / Connection																																																																																																																																																																																																					
<input type="checkbox"/> T1 or <input type="checkbox"/> T3 <input type="checkbox"/> 50 Hz or <input type="checkbox"/> 60 Hz	<input type="checkbox"/> Single-phase <input type="checkbox"/> 3-wire unbalanced three-phase <input type="checkbox"/> 3-wire balanced three-phase <input type="checkbox"/> 4-wire unbalanced three-phase <input type="checkbox"/> 4-wire balanced three-phase <input type="checkbox"/> Split-phase		<input type="checkbox"/> Ethernet or <input type="checkbox"/> RS485 <input type="checkbox"/> Tropicalization Connection diagram: TD cf: p.172																																																																																																																																																																																																					
4 - Power supply <input type="checkbox"/> 80 to 265 Vac (50/60 Hz) / 110 to 375 Vdc or <input type="checkbox"/> 19 to 58 Vdc		5 - Tropicalization <input type="checkbox"/> With <input type="checkbox"/> Without																																																																																																																																																																																																						
6 - Inputs <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="2">Current</td> <td colspan="3">Voltage</td> </tr> <tr> <td colspan="2">With current transformer or Direct</td> <td colspan="3">With voltage transformer or Direct</td> </tr> <tr> <td>Primary</td> <td>Secondary</td> <td>Primary</td> <td>Secondary</td> <td></td> </tr> <tr> <td><input type="text"/> / <input type="text"/></td> <td>A</td> <td><input type="text"/> / <input type="text"/></td> <td>V</td> <td><input type="text"/> V</td> </tr> <tr> <td colspan="2"></td> <td colspan="2"><input type="checkbox"/> Phase-phase <input type="checkbox"/> Phase-neutral ($\sqrt{3}$)</td> <td></td> </tr> </table>					Current		Voltage			With current transformer or Direct		With voltage transformer or Direct			Primary	Secondary	Primary	Secondary		<input type="text"/> / <input type="text"/>	A	<input type="text"/> / <input type="text"/>	V	<input type="text"/> V			<input type="checkbox"/> Phase-phase <input type="checkbox"/> Phase-neutral ($\sqrt{3}$)																																																																																																																																																																													
Current		Voltage																																																																																																																																																																																																						
With current transformer or Direct		With voltage transformer or Direct																																																																																																																																																																																																						
Primary	Secondary	Primary	Secondary																																																																																																																																																																																																					
<input type="text"/> / <input type="text"/>	A	<input type="text"/> / <input type="text"/>	V	<input type="text"/> V																																																																																																																																																																																																				
		<input type="checkbox"/> Phase-phase <input type="checkbox"/> Phase-neutral ($\sqrt{3}$)																																																																																																																																																																																																						
Available quantities <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td>V1 V2 V3</td> <td>U12 U23 U31</td> <td>I1 I2 I3</td> <td>F</td> <td>P1 P2 P3 Pt</td> <td>Q1 Q2 Q3 Qt</td> </tr> <tr> <td>S1 S2 S3 St</td> <td>PF1 PF2 PF3 PFt</td> <td>TANϕ</td> <td>COSϕ1 COSϕ2 COSϕ3 COSϕt</td> <td colspan="2"></td> </tr> <tr> <td>φ1 φ2 φ3 φt</td> <td>φU12/23 φU23/31 φU31/12</td> <td>V1/2 V2/3 V3/1</td> <td>I1 I2 I3 signed</td> <td colspan="2"></td> </tr> </table>					V1 V2 V3	U12 U23 U31	I1 I2 I3	F	P1 P2 P3 Pt	Q1 Q2 Q3 Qt	S1 S2 S3 St	PF1 PF2 PF3 PFt	TAN ϕ	COS ϕ 1 COS ϕ 2 COS ϕ 3 COS ϕ t			φ 1 φ 2 φ 3 φ t	φ U12/23 φ U23/31 φ U31/12	V1/2 V2/3 V3/1	I1 I2 I3 signed																																																																																																																																																																																				
V1 V2 V3	U12 U23 U31	I1 I2 I3	F	P1 P2 P3 Pt	Q1 Q2 Q3 Qt																																																																																																																																																																																																			
S1 S2 S3 St	PF1 PF2 PF3 PFt	TAN ϕ	COS ϕ 1 COS ϕ 2 COS ϕ 3 COS ϕ t																																																																																																																																																																																																					
φ 1 φ 2 φ 3 φ t	φ U12/23 φ U23/31 φ U31/12	V1/2 V2/3 V3/1	I1 I2 I3 signed																																																																																																																																																																																																					
7 - Number of analog outputs <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td><input type="checkbox"/> 0: Without (Choice of a minimum communication)</td> </tr> <tr> <td><input type="checkbox"/> 1: 1 output</td> </tr> <tr> <td><input type="checkbox"/> 2: 2 outputs (T3 model only)</td> </tr> <tr> <td><input type="checkbox"/> 3: 3 outputs (T3 model only)</td> </tr> <tr> <td><input type="checkbox"/> 4: 4 outputs (T3 model only)</td> </tr> </table>					<input type="checkbox"/> 0: Without (Choice of a minimum communication)	<input type="checkbox"/> 1: 1 output	<input type="checkbox"/> 2: 2 outputs (T3 model only)	<input type="checkbox"/> 3: 3 outputs (T3 model only)	<input type="checkbox"/> 4: 4 outputs (T3 model only)																																																																																																																																																																																															
<input type="checkbox"/> 0: Without (Choice of a minimum communication)																																																																																																																																																																																																								
<input type="checkbox"/> 1: 1 output																																																																																																																																																																																																								
<input type="checkbox"/> 2: 2 outputs (T3 model only)																																																																																																																																																																																																								
<input type="checkbox"/> 3: 3 outputs (T3 model only)																																																																																																																																																																																																								
<input type="checkbox"/> 4: 4 outputs (T3 model only)																																																																																																																																																																																																								
8 / 9 - Analog outputs calibres <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td colspan="4">Output 1 Quantity and measurement range (x)</td> <td>Transfer curve</td> <td colspan="3">Output signal (y)</td> <td colspan="2">Accuracy class (2)</td> </tr> <tr> <td colspan="4"><input type="text"/> Indicate quantity to be measured</td> <td><input type="checkbox"/> Linear</td> <td><input type="text"/> Min</td> <td><input type="text"/> Breaking point</td> <td><input type="text"/> Max</td> <td><input type="checkbox"/> mA</td> <td><input type="checkbox"/> 50 Hz</td> <td><input type="checkbox"/> 60 Hz</td> </tr> <tr> <td>Min</td> <td>Breaking point</td> <td>Max</td> <td>Unit⁽¹⁾</td> <td><input type="checkbox"/> 2 slopes</td> <td><input type="text"/> / <input type="text"/></td> <td><input type="text"/> / <input type="text"/></td> <td><input type="text"/> / <input type="text"/></td> <td><input type="checkbox"/> V</td> <tr> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="checkbox"/> Quadratic</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td colspan="4"></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td colspan="4">Output 2 Quantity and measurement range (x)</td> <td>Transfer curve</td> <td colspan="3">Output signal (y)</td> <td colspan="2">Accuracy class (2)</td> </tr> <tr> <td colspan="4"><input type="text"/> Indicate quantity to be measured</td> <td><input type="checkbox"/> Linear</td> <td><input type="text"/> Min</td> <td><input type="text"/> Breaking point</td> <td><input type="text"/> Max</td> <td><input type="checkbox"/> mA</td> <td><input type="checkbox"/> 50 Hz</td> <td><input type="checkbox"/> 60 Hz</td> </tr> <tr> <td>Min</td> <td>Breaking point</td> <td>Max</td> <td>Unit⁽¹⁾</td> <td><input type="checkbox"/> 2 slopes</td> <td><input type="text"/> / <input type="text"/></td> <td><input type="text"/> / <input type="text"/></td> <td><input type="text"/> / <input type="text"/></td> <td><input type="checkbox"/> V</td> <tr> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="checkbox"/> Quadratic</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td colspan="4"></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td colspan="4">Output 3 Quantity and measurement range (x)</td> <td>Transfer curve</td> <td colspan="3">Output signal (y)</td> <td colspan="2">Accuracy class (2)</td> </tr> <tr> <td colspan="4"><input type="text"/> Indicate quantity to be measured</td> <td><input type="checkbox"/> Linear</td> <td><input type="text"/> Min</td> <td><input type="text"/> Breaking point</td> <td><input type="text"/> Max</td> <td><input type="checkbox"/> mA</td> <td><input type="checkbox"/> 50 Hz</td> <td><input type="checkbox"/> 60 Hz</td> </tr> <tr> <td>Min</td> <td>Breaking point</td> <td>Max</td> <td>Unit⁽¹⁾</td> <td><input type="checkbox"/> 2 slopes</td> <td><input type="text"/> / <input type="text"/></td> <td><input type="text"/> / <input type="text"/></td> <td><input type="text"/> / <input type="text"/></td> <td><input type="checkbox"/> V</td> <tr> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="checkbox"/> Quadratic</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td colspan="4"></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td colspan="4">Output 4 Quantity and measurement range (x)</td> <td>Transfer curve</td> <td colspan="3">Output signal (y)</td> <td colspan="2">Accuracy class (2)</td> </tr> <tr> <td colspan="4"><input type="text"/> Indicate quantity to be measured</td> <td><input type="checkbox"/> Linear</td> <td><input type="text"/> Min</td> <td><input type="text"/> Breaking point</td> <td><input type="text"/> Max</td> <td><input type="checkbox"/> mA</td> <td><input type="checkbox"/> 50 Hz</td> <td><input type="checkbox"/> 60 Hz</td> </tr> <tr> <td>Min</td> <td>Breaking point</td> <td>Max</td> <td>Unit⁽¹⁾</td> <td><input type="checkbox"/> 2 slopes</td> <td><input type="text"/> / <input type="text"/></td> <td><input type="text"/> / <input type="text"/></td> <td><input type="text"/> / <input type="text"/></td> <td><input type="checkbox"/> V</td> <tr> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="checkbox"/> Quadratic</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td colspan="4"></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tr></tr></tr></tr></table>					Output 1 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)		<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz	Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic															Output 2 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)		<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz	Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic															Output 3 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)		<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz	Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic															Output 4 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)		<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz	Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic														
Output 1 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)																																																																																																																																																																																																
<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz																																																																																																																																																																																														
Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic															Output 2 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)		<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz	Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic															Output 3 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)		<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz	Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic															Output 4 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)		<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz	Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic																																								
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic																																																																																																																																																																																																				
Output 2 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)																																																																																																																																																																																																
<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz																																																																																																																																																																																														
Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic															Output 3 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)		<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz	Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic															Output 4 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)		<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz	Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic																																																																																									
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic																																																																																																																																																																																																				
Output 3 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)																																																																																																																																																																																																
<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz																																																																																																																																																																																														
Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic															Output 4 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)		<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz	Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic																																																																																																																																										
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic																																																																																																																																																																																																				
Output 4 Quantity and measurement range (x)				Transfer curve	Output signal (y)			Accuracy class (2)																																																																																																																																																																																																
<input type="text"/> Indicate quantity to be measured				<input type="checkbox"/> Linear	<input type="text"/> Min	<input type="text"/> Breaking point	<input type="text"/> Max	<input type="checkbox"/> mA	<input type="checkbox"/> 50 Hz	<input type="checkbox"/> 60 Hz																																																																																																																																																																																														
Min	Breaking point	Max	Unit ⁽¹⁾	<input type="checkbox"/> 2 slopes	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="text"/> / <input type="text"/>	<input type="checkbox"/> V	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic																																																																																																																																																																																											
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="checkbox"/> Quadratic																																																																																																																																																																																																				

(1) Please indicate the unit of the measurement range, e.g. W, kW or MW.

(2) These values may change according to the input and output measurement ranges.

TRIADJUST 2

SOFTWARE

Designed for quick configuration and display of all the parameters of your TRIAD 2 transducers.

DESCRIPTION


The **TRIADJUST 2** software allows quick, unlimited programming of all your TRIAD 2's parameters.

Using a PC and the optical lead supplied in each kit, connect your product's auxiliary power supply to dialog with total security. Depending on your TRIAD 2's configuration, remote communication is possible via RS485 or Ethernet.

In the Windows™ environment, initialize or simply modify the quantities measured, the measurement ranges and the analog outputs on the transducers installed.

TRIADJUST 2 also offers other functions such as **DIAGNOSIS** of your network, instantaneous **DISPLAY** of the electrical quantities and **REAL-TIME RECORDING** of the measurements in an exported file.

You can also print labels indicating the configurations and connections of your products.



- Configuration via optical head, Ethernet or RS485
- Access to all the TRIAD 2 parameters
- Diagnosis of the installation
- Label printing on all types of laser printers



Configuration

- Inputs / Outputs
- Communication
- Connection diagram
- Response time



Diagnosis

- Voltage inputs
- Current inputs
- Cabling
- Phase order
- Analog outputs
- Fresnel



Display

- Instantaneous quantities (in digital or analog form)

Recording

- In real time in exported file

ZOOM

MINIMUM CONFIGURATION

Platform: PC

Operating system: Windows 2000 or XP

Processor: Pentium-compatible

RAM: 128 MB

Hard disk: 40 GB

Drive: CD-ROM

Communication port: Local: USB 1.1 minimum

Remote: RS485 and/or Ethernet

User sectors



tertiary



industry



energy generation



energy transmission & distribution



nuclear



energy efficiency



rail

TRIADJUST 2 KIT




The TRIADJUST 2 configuration kit comprises:

- The TRIADJUST 2 software
- An optical / USB lead
- 30 sheets of blank labels
- A 230 x 185 x 45 mm carrying case

LABELS

A sheet contains two labels, one for the configuration of the inputs/outputs and the other for the programmed connection diagram. The labels can be printed on all types of laser printers.

T314		
Inputs :		
AO 1 : V1	50-60 Hz 10 000 V/ $\sqrt{3}$ 1 000 A	0.20 200 ms 750 Ω 0 V...5 773.5 V 4 mA...20 mA
AO 2 : I1		0.20 200 ms 750 Ω 0 A...1 000 A 4 mA...20 mA
AO 3 : Pt		0.20 200 ms 750 Ω 0 W...17.32 MW 4 mA...20 mA
AO 4 : F1		0.20 200 ms 750 Ω 45 Hz...55 Hz 4 mA...20 mA
Made in France		
Reference client / Own reference customer		



TO ORDER

Model	Reference	Accessories	Reference
TRIADJUST 2 kit	P01380410	Set of 30 sheets of blank labels	P01380400
		Optical/USB lead	P01330403

The TRIADJUST 2 software alone
CAN BE DOWNLOADED FREE OF CHARGE from the support
area of the www.chauvin-arnoux-energy.com website

ASSOCIATED PRODUCT



TRIAD 2

Configurable via TRIADJUST 2
Programmable digital
transducers, 1 to 4 analog
outputs. Configurable
accuracy class.

page 152